

INSTALLATION, USE AND CARE



Ensure that the range hood is installed according to the manufacturer's guidelines. Installation should be performed by a qualified professional to ensure proper venting and secure mounting.

Proper Ventilation: Make sure the venting system is correctly installed, with the ducting running to the outside of the home to efficiently remove air contaminants.

Choosing the Right Fan Speed: Use the appropriate fan speed based on your cooking activities.

Using the Rangehood While Cooking: Turn on the rangehood before you start cooking to ensure it effectively captures smoke and odors from the beginning.

Use a Voltage Protector: Protect your unit and warranty by using a voltage protector.





Avoid running the fan on high for prolonged periods as this can cause unnecessary wear on the motor.

Avoiding Excessive Grease Build-Up: Clean or replace the rangehood filters regularly to prevent grease build-up, which can reduce the efficiency of the appliance and pose a fire hazard. Metal filters should be washed with warm soapy water or in the dishwasher, while charcoal filters should be replaced as recommended by the manufacturer.

Avoiding Obstructions: Ensure that there are no obstructions in the ductwork that could hinder airflow. Periodically inspect the ducts for any blockages or damage.

Avoid using abrasive cleaners or scouring pads, as they can damage the finish of the rangehood.

For Residential use ONLY:

Using this unit other than for Residential use VOIDS all warranties.

Please read the Manual. Familiarize yourself with your manual. Not only does it cover, basic operational use. You can maximize the use of your machine by learning its features.

PLEASE ENSURE all of the above guidelines are taken into consideration before making a service complaint. It may be a fault of the unit; it may be an improper installation or a user issue. Both are not covered by warranty and you would have to pay a fee.

Repairs by an unauthorized technician VOIDS your WARRANTY.