



# INSTALLATION, USE AND CARE

**ONCE** your Refrigerator is in place, after transporting or moving a refrigerator, **wait 6-8 hours** before plugging in. Run the unit empty for 2 hours before partially loading.

**ENSURE** the power supply meets electrical standards and the output is 110-120 V/60 Hz. It must be correctly grounded.



**VOLTAGE  
PROTECTOR**



**PLEASE DO NOT** use harsh/abrasive or ammonia based cleaning products. This will cause rusting, which **is not covered by your warranty**.

If you think the unit is not performing as it should, **please verify your settings** are set at middle or at factory recommended settings and works for 48 hours. Ensure items are not packed near the air flow vents.

**FILTERS are not covered** under warranty. Based on the quality of water in your area there is no minimum time-frame for a filter to be changed.

For residential use **ONLY**:

Using this unit other than for residential use **VOIDS** all warranties.



**Please read the Manual.** Familiarize yourself with your manual. Not only does it cover, basic operational use. You can maximize the use of your machine by learning its features.

**PLEASE ENSURE** all of the above guidelines are taken into consideration before making a service complaint. It may be a fault of the unit; it may be an improper installation or a user issue. **Both are not covered by warranty and you would have to pay a fee.**

**Repairs by an unauthorized technician VOIDS your WARRANTY.**

