



INSTALLATION, USE AND CARE

Use HE (High-Efficiency) Detergents ONLY:
HE detergents suds very little vs regular detergent, which suds and over flows into the outer tub, and causes services issues.



About High-Efficiency Washers:

High Efficiency washers are designed to save on electricity and water; thus **SAVING YOU MONEY**. The use of 'HE' detergent is **necessary** as the machine use less water.

Level Your Washer. Your washer has adjustable leveling legs. Ensure the washer is leveled by adjusting legs if needed. **DO NOT** place on bricks, wood, etc.

Use a Voltage Protector: Protect your unit and warranty by using a voltage protector.



**VOLTAGE
PROTECTOR**

Use both inlet hose:

Connect both inlet hoses. If needed use a "Y" connector. Ensure the drain hose is in a vertical drain pipe 36 minimum in height.

Minimum water pressure required 20 psi

For residential use **ONLY**: Using this unit other than for residential use **VOIDS** all warranties.

NOTE: Please remove shipping bolt **before use**.

Please read the Manual. Familiarize yourself with your manual. Not only does it cover, basic operational use. You can maximize the use of your machine by learning its features.

PLEASE ENSURE all of the above guidelines are taken into consideration before making a service complaint. It may be a fault of the unit; it may be an improper installation or a user issue. **Both are not covered by warranty and you would have to pay a fee.**

Repairs by an unauthorized technician **VOIDS** your **WARRANTY**.

