

## INSTALLATION, USE AND CARE



Ensure the Spacemaker appliance is installed by a qualified professional according to the manufacturer's guidelines. Proper installation is crucial for safe and efficient operation.

Since Spacemaker appliances, like microwaves and laundry units, often operate in confined spaces, ensure there is proper ventilation to prevent overheating.

Regular Maintenance: Schedule regular maintenance checks as recommended in the user manual.

Refer to the troubleshooting section of your user manual if the appliance isn't functioning correctly. If the problem persists, contact GE customer service or a qualified technician.

**Energy Efficiency**: Use energy-saving settings when available to reduce energy consumption.





Please Avoid Overloading: Overloading Spacemaker appliances, whether microwaves or laundry units, can lead to poor performance and potential damage.

Do not block the air vents, as this could lead to appliance malfunction or reduced efficiency.

Do not operate microwaves when empty. Always use microwave-safe cookware and cover food to prevent splatters.

Do not store items on top of the Spacemaker appliances, especially microwaves, as this can block vents or accidentally activate the controls.

Ensure that the Spacemaker appliance is connected to the correct power supply as specified in the user manual. Using the wrong voltage can damage the appliance.

## For Residential use ONLY:

Using this unit other than for Residential use **VOIDS** all warranties.

Please read the Manual. Familiarize yourself with your manual. Not only does it cover, basic operational use. You can maximize the use of your machine by learning its features.

PLEASE ENSURE all of the above guidelines are taken into consideration before making a service complaint. It may be a fault of the unit; it may be an improper installation or a user issue. Both are not covered by warranty and you would have to pay a fee.

Repairs by an unauthorized technician VOIDS your WARRANTY.